



Thank you for your purchase of the **MelloTremo™** by Tone Freak Effects! The **MelloTremo™** utilizes an old tremolo circuit that has been modified for increased flexibility. The **MelloTremo™** is just that, a mellow, warm sounding tremolo.

CONTROLS

Rate: Increase the rate of the tremolo by turning the knob clockwise. Turning the knob counter clockwise will decrease the gain.

Depth: Turning the knob clockwise will increase the depth. Counter clockwise will decrease the depth. You will notice that as you increase the depth, the tremolo effect increase. Decreasing the depth makes less noticeable.

Volume: To increase the output volume, turn the

knob clockwise. By turning the volume control counter clockwise, you will decrease the output volume.

The **MelloTremo™** uses a 9V battery or a 2.1 mm center negative pin power adapter.